


Liano Gazebo

10' x 12'

□ □ □ □ □ □ □ Model: KWAP229 □ □ □ □ □ □ □




Assembly manual / Manuel d'assemblage Liano Gazebo 10'X12' - KWAP229

Please carefully unpack each of the components and hardware. Check the components against the parts list and make sure there are no missing parts.

For ease of assembly, it is recommended to have 2 or more people.
Assembly can take 4-6 Hours.

Veillez déballer soigneusement chacune des composantes et le matériel.
Vérifiez les composantes par rapport à la liste des pièces et assurez-vous qu'il n'y a pas de pièces manquantes.

Pour faciliter l'assemblage, il est recommandé d'être 2 personnes ou plus.
Peut prendre entre 4-6 heures.



NOTICE

IMPORTANT: A gazebo may require a municipal permit and may be subject to construction standards. Please inform the relevant authorities.

SECURITY RULES

It is very important to read and follow the safety rules before assembling and when using the shelter.

It is recommended to avoid the final installation of the gazebo in a strong wind corridor.

1: It is important to plan enough time to complete the assembly. This shelter should not be left unattended if the assembly is not completely finished, even if it is screwed to the ground.

2: Always install the structure on level ground. The shelter must be anchored to a floor of wood, concrete or stone slabs using the appropriate screws for each type of flooring.

3: Plan a space of at least five feet around the structure for mounting.

4: Do not use the structure as support; use a stepladder when needed.

5: Some parts may have sharp sides. It is recommended to wear protective gloves.

WARNING: KEEP ANY FLAME OR HEAT SOURCE AWAY FROM ALL FABRICS INCLUDING BBQ'S. The fabrics meet the flammability requirements of CPAI-84. They can burn if left in contact with a flame. Application of a foreign substance to the tissue may decrease, or remove, its flammability properties.

If any of these above-mentioned instructions is not followed the warranty will be voided.

OPERATION

The gazebo is intended to be used as a shelter, not to use it for anything other than what it was designed for.

The gazebo can be left outdoors all year long. **You must remove the roof as well as the mosquito nets during the winter.**

Do not place any heating appliance, heat source or exposed flame under the gazebo or within five (5) feet.

Do not hang or hang excess weight 6.8kg (15lbs).

If any of these above-mentioned instructions is not followed the warranty will be voided.

MAINTENANCE

Periodically check that the gazebo is well anchored to the ground to enjoy its safe use.

Periodically check that all screws are tight before using the shelter.

To place your order and identify the parts to be replaced, refer to the model number of the gazebo and the letters that are indicated on the parts list.

It is preferable to ensure the longevity by treating the roof with a UV and waterproofing product.

CARE AND CLEANING

For cleaning the gazebo, use a mild soap and wash with warm water with a sponge or microfiber cloth. Rinse with clear water.

Do not put mosquito nets in a washing machine or dryer.

Mosquito nets must be removed and stored in a dry place during the winter.

WARRANTY

From the date of purchase and not transferable, the buyer has 30 days to make a claim for all missing or damaged parts in the box (es). If this is the case, you must contact the retailer. Proof of purchase is necessary. Shipping costs are included within 100 km of the store, for any missing parts or manufacturing defect. Damaged parts are no longer under warranty after 30 days and claims will be at the expense of the buyer.

IMPORTANT: This gazebo is not a permanent structure. The structure can be left outdoors for all seasons, but you must remove the roof and mosquito nets during the winter. Make sure the roof and screens are dry before storage and must be stored in a dry place.

This gazebo is guaranteed against manufacturing defects based on normal use:

- 2 years on the structure and fading only for the roof
- 1 year on mosquito nets

Limited warranty is applicable on parts only.

WHAT IS NOT GUARANTEED:

- The labor on the assembly of the gazebo
- Damage caused by vandalism, abuse or misuse of this product
- Damage caused by extreme weather conditions such as thunderstorms, snowstorms, windstorms and hail.
- Water infiltration and holes in the roof panels are not covered.
- Damage due to the product not installed on level ground and / or anchored with appropriate screws.
- Damage due to hanging or hanging weight exceeding 6.8kg (15lbs).

PRE-ASSEMBLY

Check that all parts of the gazebo are in the box (es) before assembly. If this is not the case, you must contact the retailer.

Follow all instructions to ensure the solidity of the gazebo.

It is important to plan enough time to complete the assembly. This shelter should not be left unattended if the assembly is not completely finished, even if it is screwed to the ground.

To prevent damage to the gazebo and its components, place all parts on a soft surface and use appropriate tools.

During assembly do not use the structure as a support; use a stepladder when needed.

Keep the User's Guide and parts list for future needs.

TOOLS REQUIRED (Not included in boxes)



LEVEL



PHILLIPS SCREW DRIVER




SAFETY GOGGLES



SAFETY HAT



GLOVES



DRILL







STEPLADDER

In case of damage or missing part, contact the customer service at 1-800-320-2979 or by email service@clubpiscine.ca.





www.clubpiscine.ca

PARTS LIST / LISTE DE PIÈCES


PART PIECE	ITEM/ARTICLE	DESCRIPTION	QTY/QTÉ
A		PILLAR / PILIER	4
B		CROSSBEAM 1 /MOULURE 1	2
B1		CROSSBEAM 2 /MOULURE 2	2
C		CROSSBEAM 3 /MOULURE 3	2
C1		CROSSBEAM 4 /MOULURE 4	2
D		CROSSBEAM CONNECTOR 1 CONNECTEUR DE MOULURE 1	2
D1		CROSSBEAM CONNECTOR 2 CONNECTEUR DE MOULURE 2	2
E		ROOF RIBS 1 SUPPORT DE TOIT 1	6
F		ROOF RIBS 2 SUPPORT DE TOIT 2	4
F1		ROOF RIBS 3 SUPPORT DE TOIT 3	4
G		ROOF CONNECTOR CONNECTEUR DE TOIT	1
H		CURTAIN TUBE 1 TUBE DE RIDEAU 1	4
H1		CURTAIN TUBE 2 TUBE DE RIDEAU 2	4
I		FOOT BASE 1 BASE DE PIED 1	4
I1		FOOT BASE 2 BASE DE PIED 2	4
J		CORNER GAP COVER CACHE-JOINT DE COIN	4
K		CONNECTOR CONNECTEUR	6

PARTS LIST / LISTE DE PIÈCES

PART PIECE	ITEM/ARTICLE	DESCRIPTION	QTY/QTÉ
L		ROOF TOIT	1
N		MOSQUITO NETTING MOUSTIQUAIRE	4
P		NETTING HOOK CROCHET MOUSTIQUAIRE	36+1
X	 M6*15	BOLT (M6*15) BOULON (M6*15)	110+2
X1	 M6*30	BOLT (M6*30) BOULON (M6*30)	24+1
R		WRENCH CLÉ	1
S		ALLEN WRENCH CLÉ ALLEN	1
T		GROUND NAIL CLOU AU SOL	8


STEP1

ÉTAPE 1




STEP2

ÉTAPE 2




STEP3

ÉTAPE 3




STEP4

ÉTAPE 4



STEP5

ÉTAPE 5



STEP6

ÉTAPE 6

