
User guide



Arena Pergola 10'X13'

Model: LGMF1631



www.clubpiscine.ca




Table of Contents

Regulations	2	Care and Cleaning	3
Safety Information	2	Pre-assembly	4
Maintenance	2	-Planning installation	4
Warranty	3	-Tools required	4
Operation	3 -Hardware package		4-5
·		-Parts List	6
		Assembly Instructions	7-13

Regulations

IMPORTANT: A pergola may entail to purchase a municipal permit or be subject to specific building codes. It is the consumer's responsibilty to inform themselves of any restrictions.

Safety Information

It is important to read and follow all safety information prior to assembly of the unit as well as during usage to reduce risk of injury and avoid damage to the product and its surroundings.

It is highly recommended to avoid installing and settling the pergola in a corridor of heavy wind.

- 1: You must schedule enough time to complete the assembly of the pergola For safety issues you must not leave the unit unattended if it is not completed, even if it is already anchored to the ground.
- 2: A minimum of 3 people are required to assemble the pergola.
- 3: The unit must be assembled on a level platform (wood deck, stone tile or concrete) and must be anchored using appropriate screws for that flooring.
- 4: To avoid damages the assembly of the unit should be constructed no less than 5 feet from any fixed obstruction.
- 5: Some assembly parts contain sharp edges; you should wear protective gloves when handling these items.

IMPORTANT: Failure to follow any of the above instructions will void the warranty. For any assistance regarding your pergola warranty, contact the customer service department of the Club Piscine store where you purchased your product.

Maintenance

Check periodically that the pergola is anchored properly to the floor or ground to enjoy its safe usage.

Check periodically that all screws are tight to maintain the solidity of the structure.

The pergola can be left outside year round. You MUST, however, remove any snow accumulation at all times. Failure to do so will nullify the Warranty.

IMPORTANT: Failure to follow any of the above instructions will void the warranty. For any assistance regarding your pergola warranty, contact the customer service department of the Club Piscine store where you purchased your product.

Warranty

NOTICE: The purchaser of this product has 30 days from date of purchase or delivery to verify their merchandise. Shipping costs are included within 100 km of the store, for any missing parts or manufacturing defect. Damaged parts will not be under warranty after the 30-day period and all claims will be the responsibility of the purchaser. DO NOT ASSEMBLE YOUR PERGOLA IF PARTS ARE DAMAGED. Contact your retailer Club Piscine immediately.

Proof of purchase is necessary at all times. This warranty is not transferable.

IMPORTANT: This product is not a permanent structure. The solarium can be left out during all seasons however snow accumulation must be removed at all times. During the winter, be sure to clear the snow from the posts to ensure that water drains properly from the posts through the drainage hole. Screens and panels should be removed and stored dry over winter. Roof louvers should be opened vertically during the winter. It is possible to experience water leakage during heavy precipitation.

This warranty is based on normal use of the product.

This product is guaranteed against defective materials from the factory;

- One(1) year on the frame against discoloration.
- One(1) year on the louvers against rust and discoloration.
- Limited warranty applicable on parts only.

WHAT IS NOT COVERED

- Any and all labor from the assembly of the pergola
- Damages caused by abuse, misuse of this product or vandalism.
- Damages due to extreme natural weather conditions such as, and not limited to, rainstorms, hailstorms, wind storms and snow storms.
- Water infiltration
- Damages due to the product not installed on a level ground and anchored down with appropriate screws.
- Damages caused by hanging or suspending objects heavier than 6.8kg (15lbs.) IMPORTANT: Failure to follow any of the above instructions will void the warranty. For any assistance regarding your pergola warranty, contact the customer service

department of the Club Piscine store where you purchased your product.

Operation

The pergola is intended to be used as a shelter; do not misuse the product for other than what it is designed for.

This pergola can be left out during all seasons During the winter, be sure to clear the snow from the posts to ensure that water drains properly from the posts through the drainage hole. Screens and panels should be removed and stored dry over winter. Roof louvers should be opened vertically during the winter.

Do not place any type of heat conductor under, or within 5 feet of, the pergola including, but not limited to, a barbeque grill or space heater.

Do not suspend or hang from the structure any object(s) exceeding 6.8kg (15lbs).

IMPORTANT: Failure to follow any of the above instructions will void the warranty. For any assistance regarding your pergola warranty, contact the customer service department of the Club Piscine store where you purchased your product.

Care and Cleaning

For cleaning, use a domestic soap or detergent and wash with warm water using a sponge or fabric. Rinse with clean water.

Pre-assembly

PLANNING INSTALLATION

Make sure that all the parts are in the boxes before starting the assembly. Follow all assembly instructions to assure proper construction.


You must schedule enough time to complete the assembly. You cannot leave the unit unattended if it is not fully assembled, even if it is already anchored to the ground.

In order to avoid damage to the pergola and its components, place all parts on a soft surface and use appropriate tools.

During assembly, do not use the structure as a support. Use a stepladder.

Keep this User Guide and Parts List for future reference.

TOOLS REQUIRED (Not included in box)





HARDWARE PACKAGE INCLUDED


1#			62	3#		(-)	6
Bolt (M6*	16)			Bolt (M5*	8)		Qty
5#			2	6#			1
Bolt (M8*	32))		Nut and s	pacer (M6)		Qty
7#			1	8#		(-)	112
Nut and sp	acer (M8)		Qty	Screw (S	T3.5*16)		Qty
9#		- -	112				
Bolt (4*6)	Ŭ		Qty				
	= S6 x1	S4 x1		S10 x1	5	S13 <u>x1</u> x2	

Pre-assembly


PARTS LIST









STEP 3







Assembly

STEP 5





STEP 7



Assembly
IMPORTANT Follow to follow the following for the state of
IMPORTANT : Failure to follow any of the above instructions will void the warranty.
For any assistance regarding your pergola warranty, contact the customer service department of the Club Piscine store where you purchased your product.

